Do not disconnect the terminals while the engine is running.

Do not charge the batteries without disconnecting the terminals first.

Do not push the vehicle to start the engine if it is fitted with a 6-speed electronic gearbox system.

Before disconnecting the battery

Wait 2 minutes after switching off the ignition before disconnecting the battery.

Close the windows and the doors before disconnecting the battery.

Following reconnection of the battery

Following reconnection of the battery, switch on the ignition and wait 1 minute before starting to permit initialisation of the electronic systems. However, if problems are encountered following this operation, contact a CITROËN dealer.

Referring to the corresponding section, you must yourself reinitialise (depending on equipment):

- the remote control key,
- the one-touch electric windows,
- the settings of the multifunction screen,
- the audio equipment radio stations,
- the GPS satellite navigation system.

ENERGY ECONOMY MODE

System which manages the duration of use of certain functions to conserve a sufficient level of charge in the battery.

After the engine has stopped, you can still use functions such as the audio and telematics system, windscreen wipers, dipped beam headlamps, courtesy lamps, etc. for a maximum combined duration of thirty minutes.

Switching to economy mode

Once the thirty minutes are over, a message appears on the multi-function screen indicating that the vehicle has switched to economy mode and the active functions are put on standby.

Exiting economy mode

These functions are reactivated automatically next time the vehicle is driven.

In order to resume the use of these functions immediately, start the engine and let it run:

- for less than ten minutes to use the equipment for an equivalent duration,
- for more than ten minutes to use the equipment for approximately thirty minutes.

A flat battery prevents the engine from starting (refer to the corresponding paragraph).